

## **Rip Rap Machine & Related Equipment**

Developed by:		Approved by:	Date create	ed:	Last revision:
Jason M. Moffatt	(	G. Kaluzniak	January , 2	016	December 1, 2022
Possible Hazards Pre	sent	sent Personal Protection Required		Additional Training	
<ul> <li>Electrical</li> <li>Working at heights, Ladders, Falling</li> <li>Overhead hazards</li> <li>Excavations</li> <li>Traffic</li> <li>Communication</li> <li>Mobile Equipment</li> </ul>		<ul> <li>CSA Footwear</li> <li>CSA Safety Glasses</li> <li>Hard Hat</li> <li>Gloves</li> <li>High Visibility Clothing</li> </ul>		-	Loader Orientation Rip Rap Machine Operation Generator Orientation PPE

- 1. Check all fluids on feeder, loaders, and generator (oil, coolant, hydraulic fluids, Etc.)
- 2. Start machines and allow time to warm up (at least 5 mins longer for winter operation).
- 3. Ensure main breaker is turned off and generator door is locked (lockout procedure.
- 4. Grease all points on loaders a minimum of once a day.
- 5. Grease rock plant (all bearings at both ends of each conveyor) a minimum of once a day.
- 6. Clean out (shovel) around the bottom of conveyors and around plant (errant rocks etc.)
- 7. Unlock generator door and turn on main breaker switch.
- 8. Start main take away belts. Ensure there are no strange noises and that they are running smooth.
- 9. Start cross-over belt. Ensure there are no strange sounds and that it's running smooth. Adjust scraper accordingly.
- 10. Start feeder. Ensure there are no strange sounds and that it's running smooth.
- 11 Set feeder speed at 45 to begin. Once material feed rate is established when loading is started, speed can be adjusted accordingly.
- 12. Ensure loading ramp is level and secure, begin loading material into plant.
- 13. As loading material continues, watch plant, conveyors, etc. for signs of malfunction (sudden stops, plugs, jams, smoke, etc.).
- 14. Watch conveyor belts to be sure they are running centered on head rollers. Adjust accordingly immediately to prevent machine/belt malfunction.
- 15. Take away sorted product as it's produced to ensure that overstocking of piles does not occur.
- 16. Watch end of long conveyor (stacker) to ensure that the pile does not build to a point that it interferers with the belt (move stacker accordingly).
- 17. Ensure that all material is cleared from the individual equipment pieces prior to shutdown.



<ul><li>18. Shut down all belts and feeder.</li><li>19. Allow generator to cool down for at least 5 minutes prior to shutting it down.</li></ul>					
Documentation/Legislation					
Workplace Safety and Health Regulation, M.R. 217/2006	This Safe Work Procedure will be reviewed anytime the task, equipment				
6 Personal Protective Equipment 16 Machines, Tools and Robots 20 Vehicular and Pedestrian Traffic 22 Powered Mobile Equipment	or materials change and at a minimum every three years.				