



Concrete Saw - Walk Behind - Blade Installation

Developed by:		Approved by:		Date created:		Last revision:		
Jason M. Moffatt		G. Kaluzniak		January , 2016		December 1, 2022		
Possible Hazards Present			Personal Protection Required			Additional Training		
<ul style="list-style-type: none"> - Pinch Points - Cuts 			<ul style="list-style-type: none"> - CSA Footwear - CSA Safety Glasses 					
<ol style="list-style-type: none"> 1. Raise the blade guard to it's highest position. 2. Open blade nut access door, remove the blade shaft nut turning clockwise, remove the outside collar, and raise the blade guard. 3. Position the blade beneath the cutting head and slide the blade into blade guard 4. Locate blade shaft then slide the blade bore hole onto the blade shaft. 5. Slide the outside blade shaft collar onto the blade shaft, tighten the blade shaft nut counter-clockwise securely against the outside collar. 6. Close the blade nut access door. 								
<p>Documentation/Legislation Workplace Safety and Health Regulation, M.R. 217/2006</p> <p>6 - Personal Protective Equipment 16 - Machine, Tools, and Robots</p>					<p>This Safe Work Procedure will be reviewed anytime the task, equipment or materials change and at a minimum every three years.</p>			