



Concrete Saw - Walk Behind – Operation

Developed by:		Approved by:	Date created:	Last revision:
Jason M. Moffatt		G. Kaluzniak	January , 2016	December 1, 2022
Possible Hazards Present	Personal Protection Required		Additional Training	
<ul style="list-style-type: none"> - Pinch Points - Fire/Explosion - Burns - Inhalation of lethal gasses/dust 	<ul style="list-style-type: none"> - CSA Footwear - CSA Safety Glasses - Hard Hat - Hearing Protection - Respirator 		<ul style="list-style-type: none"> - PPE - Fit Test 	
<ol style="list-style-type: none"> 1. Check engine oil level. 2. Raise saw to the full upright position, do not let the blade come in contact with the ground. 3. Maneuver the saw to the desired starting point. 4. Ensure that the emergency stop switch is in the up position. 5. Turn engine On/Off switch to the "On" 6. Engage choke as necessary. 7. Pull start rope. If engine does not start within three to five pulls of start rope, refer to engine owner's manual. 8. Slowly lower the blade by rotating the hand wheel clockwise until the desired depth of cut is reached. 9. Only move the saw in revers with the blade in raised position. 10. When moving the saw to a new location, ensure blade is not touching the ground. 				
<p>Documentation/Legislation Workplace Safety and Health Regulation, M.R. 217/2006</p> <p>6 - Personal Protective Equipment 16 - Machines, Tools, and Robots 6.15 Respiratory Protective Equipment</p>			<p>This Safe Work Procedure will be reviewed anytime the task, equipment or materials change and at a minimum every three years.</p>	