



Masonry Saw - Wet Cutting

| | | | | |
|--|--|--|---|---|
| Developed by: | | Approved by: | Date created: | Last revision: |
| Jason M. Moffatt | | G. Kaluzniak | January , 2016 | December 1, 2022 |
| Possible Hazards Present | | Personal Protection Required | | Additional Training |
| <ul style="list-style-type: none"> - Pinch Points - Cuts - Electrical | | <ul style="list-style-type: none"> - CSA Footwear - CSA Safety Glasses | | <ul style="list-style-type: none"> - PPE |
| <ol style="list-style-type: none"> 1. Prepare water supply 2. Install water curtain on cutting head pivot bar. 3. Start motor and be certain that both sides of the blade are getting water. Handle on petcock should be turned in line with the water flow. 4. Ensure the water covers the bottom of pump at all times. | | | | |
| Documentation/Legislation Workplace Safety and Health Regulation, M.R. 217/2006 6 Personal Protective Equipment 16 Machines, Tools and Robots | | | <p>This Safe Work Procedure will be reviewed anytime the task, equipment or materials change and at a minimum every three years.</p> | |