



Portable Toilets – Washing

Developed by:		Approved by:	Date created:	Last revision:
Jason M. Moffatt		G. Kaluzniak	January , 2016	December 1, 2022
Possible Hazards Present		Personal Protection Required		Additional Training
<ul style="list-style-type: none"> - Peripheral traffic - Weather conditions - Driving/backing into/over people or objects 		<ul style="list-style-type: none"> - CSA Rubber Boots - CSA Safety Glasses - Heavy Gloves - Up to elbows - Respiratory Equipment - Face Shield 		<ul style="list-style-type: none"> - PPE - Fit Test
<ol style="list-style-type: none"> 1. Open north-east door for ventilation. 2. Open large door in storage shed. 3. Requires 2 employees and both shall be wearing respiratory equipment. 4. 1 employee must operate the pump out truck, the other must bring the toilets to the large door area using the pallet jack. 5. Toilets are to be pumped outside the building where the pump truck is. Under no circumstances should the pump truck be inside the building. 6. Turn on water supply to pressure washer. 7. Ensure that you are wearing a face shield before using pressure washer. 8. Ensure that proper sanitizing solution is mixed and is evenly sprayed on unit. 9. Pull out wand and amount of hose needed. 10. Turn on power supply and maintain a firm grip on the wand. 11. When clean, shut off power first and then water supply. 12. Place Quick Scents Toilet Deodorizers in the tank along with 5 gallons of water. 13. Coil up hose and wand, put away. 14. Ensure that the area is properly cleaned when you are finished. 15. Remove toilets from storage area and bring them to the appropriate storage area outside. 				
Documentation/Legislation Workplace Safety and Health Regulation, M.R. 217/2006 6 Personal Protective Equipment 6.15 Respiratory Protective Equipment 20 Vehicular and Pedestrian Traffic			<p>This Safe Work Procedure will be reviewed anytime the task, equipment or materials change and at a minimum every three years.</p>	