



SAFE WORK PRACTICE

TITLE	Spray Painting
GENERAL	Protecting workers from injuries associated with spray painting operations.
APPLICATION	Spray painting is an integral part of construction work, which must be performed by trained workers.
PROTECTIVE MECHANISMS	Safe work procedure Occupational exposure limits WHMIS (SDS) Permit system PPE ERP (Emergency Response Plan)
SELECTION AND USE	As per safe work procedure Provincial OH&S Legislation
SUPERVISOR RESPONSIBILITY	Supervisors are responsible to facilitate and/or provide proper instruction to their workers on protection requirements and training. Selection of equipment Hazard Assessment
WORKER RESPONSIBILITY	<ol style="list-style-type: none"> 1. Ensure you are fully trained. 2. Ensure you are acquainted with safe work procedures. 3. Follow manufacturer's recommendations. 4. Ensure all sources of ignition are eliminated or controlled. 5. Ensure equipment is grounded. 6. Ensure area is ventilated. 7. Do not smoke around spray painting operations. 8. Ensure warning signs are in place. 9. Practice good housekeeping. 10. Use proper PPE when spray painting. 11. Follow spray painting safe work procedures step by step.