



TEXTURE APPLICATION

Developed by: B White Safety Coordinator	Approved by: Jason Moffat	Date created: July 2013	Last revision: December 1, 2022
Possible Hazards Present	Personal Protection Required	Additional Training	
<ul style="list-style-type: none"> - Muscle strain - Splash in eye - Shock from mixer 	<ul style="list-style-type: none"> - CSA safety boots - CSA hard hat - Safety Glasses - Gloves 	<ul style="list-style-type: none"> - PPE 	
<ol style="list-style-type: none"> 1. Mix water and joint compound using electric drill and stirring bit. 2. Mix until consistency is similar to wallpaper paste. 3. Prepare a paint roller with extended handle and long nap roller. 4. Dip roller into joint compound until completely submerged. Tap on edge of bucket to get rid of excess compound. 5. Begin rolling on compound at one corner and work across ceiling to other side. Dip roller frequently to ensure a thick application. Apply to whole ceiling prior to texturing. 6. Use a trowel to apply texture. If you make a mistake then add more texture and redo. 7. Allow compound to dry 24 hours before painting. 8. REPORT ANY DANGEROUS SITUATIONS TO THE SUPERVISOR. 			
<p>Documentation/Legislation Workplace Safety and Health Regulation, M.R. 217/2006</p> <p>6 Personal Protective Equipment 16 Machines, Tools and Robots</p> <p>Refer to Mud Mixing SOP</p>		<p>This Safe Work Procedure will be reviewed anytime the task, equipment or materials change and at a minimum every three years.</p>	