

Front End Loader

Developed by:	Approved by:		Date created:		Last revision:
B White	Jason Moffat		April 2009		December 1, 2022
Safety Coordinator			-		
Possible Hazards Present		Personal Protection		Additional Training	
		Required			
 Slips/falls when entering/exiting loader Pinch points Tips/roll overs Pedestrians Overhead wires 		CSA approved		- Operator training	

- 1. Operator must be trained to operate the specific loader.
- Operator must read and understand the operator's manual.
- 3. Complete a pre op inspection of the loader
- 4. Complete daily maintenance checks (fluids, etc.)
- 5. Check the work area for hazards. (holes, overhead lines, other equipment and personnel)
- 6. Ensure all utilities have been marked.
- 7. Enter and exit loader using proper procedure
- 8. Start the loader and check all gauges, lights and alarms.
- 9. Always wear the seat belt.
- 10. Operate the controls from the seat only.
- 11. Ensure loader is operated on level ground.
- 12. Do not exceed loader or bucket weight capacities.
- 13. Ensure the load in the bucket is balanced.
- 14. Do not turn when the bucket is raised.
- 15. Travel with the bucket in the lowest possible position.
- 16. Ensure the park brake is engaged and bucket is lowered before exiting the loader.
- 17. Do not allow passengers.
- 18. Do not use the bucket as a work platform.
- 19. REPORT ANY DANGEROUS SITUATIONS TO THE SUPERVISOR.

Documentation/Legislation

Workplace Safety and Health Regulation, M.R. 217/2006

20 Vehicular and Pedestrian Traffic22 Powered Mobile Equipment

This Safe Work Procedure will be reviewed anytime the task, equipment or materials change and at a minimum every three years.