



Skid Steer Operation

Developed by:	Approved by:	Date created:	Last revision:
B White Safety Coordinator	Jason Moffat	October 2009	December 1, 2022
Possible Hazards Present	Personal Protection Required	Additional Training	
<ul style="list-style-type: none"> - Pinch points - Roll over - Overhead wires - Noise - Dust 	<ul style="list-style-type: none"> - CSA approved footwear - CSA approved hardhat - CSA approved eye and hearing protection - Dust mask when Needed 	<ul style="list-style-type: none"> - Operator Certificate - PPE 	
<ol style="list-style-type: none"> 1. Read and understand the operator's manual. 2. Familiarize yourself with warning devices, gauges and controls. 3. Wear recommended PPE. 4. Complete a pre-op inspection of the machine checking fluid levels, emergency devices, controls, etc. Ensure all attachments are secure. 5. Check surroundings. (soil condition, overhead power lines, other workers, equipment, etc.) 6. Never remove rollover protection. 7. Seat belt and seat bar must always be used. 8. Do not exceed load rating. 9. Keep the bucket as low as possible when travelling and turning. 10. Avoid steep slopes and terrain, always travel up or down slopes, never across. 11. Move up and down slopes with the heavy end uphill, bucket when loaded, rear when not loaded. 12. Avoid dumping over fence posts or other obstacles which may enter the cab if the machine tips forward do to a heavy load being raised. 13. Keep all limbs inside the cab during operation. 14. Never allow riders. 15. Never use the bucket as a work platform. 16. If the loader starts "bucking" remove hands and feet from the controls. 17. NEVER OPERATE THE CONTROLS WHILE OUTSIDE THE CAB. 18. REPORT ANY DANGEROUS SITUATIONS TO THE SUPERVISOR. 			
<u>Documentation/Legislation</u> Workplace Safety and Health Regulation, M.R. 217/2006 6 Personal Protective Equipment 16 Machines, Tools and Robots 20 Vehicular and Pedestrian Traffic 22 Powered Mobile Equipment		<p>This Safe Work Procedure will be reviewed anytime the task, equipment or materials change and at a minimum every three years.</p>	