

Countertop Miter Saw

Developed by:	Approved by:		Date created:		Last revision:
Walter Lavallee		Ryan Adams Karissa Deg	May 202	4	
Possible Hazards Present		Personal Protection Required		Additional Training	
Electrical ShockNoiseDebris in eyesMSI back injury		Steel Toed BootsHearing ProtectionSafety Glasses		-	Material Handling PPE

- 1. No worker shall operate any power tool, or similar type of equipment unless they are familiar with the use and operation of the equipment and have received specific instruction on its use and operations.
- Inspect the machine prior to use and adjust the machine to the desired cutting angle.
- 3. Turn on both power switches on the wall.
- 4. Turn on the master power switch on left side.
- 5. Using proper lifting techniques, position the material to be cut on the stand.
- 6. Open guards, place material into the cutting position.
- 7. Lower clamps into place by activating lever on each corresponding side.
- 8. Close guards.
- 9. Start saw by pushing saw start button.
- 10. Adjust the movement speed of the blade by turning dial.
- 11. Push and hold the blade return button to return saw blade to start position.
- 12. Turn off saw.
- 13. Open guards.
- 14. Release clamps on both sides.
- 15. Remove material from saw housing.
- 16. Turn off master power switch.
- 17. Turn off power on wall

Workplace Safety and Health Regulations, 2022	This Safe Work Procedure will be reviewed anytime the task, equipment
Operator's Manual 6 - PPE 16 – Machines, tools, robots 16.5- Safeguards	or materials change and at a minimum every three years.